

BFAF - Bare Fiber Adapters

Description

The BFAF Adapter introduces new innovated series of Bare Fiber Adapters. It is designed to be used for temporarily connection of unterminated fibers to meet test, service and communications requirements. Adapters are available with FC and SC connectors.

Features:

- Simply strip and cleave your fiber and insert into the Bare Fiber Adapter
- Broken fibers are removed with piano wire allowing hundreds of insertions
- Accommodates 125 µm clad fiber with Insertion loss < 1 dB



BFAF-PC-Z-1



BFAF-SC-Z-1

Application:

- Quick terminating fibers
- Cable checking
- Fiber optic component production

Ordering code:

